

Lighter Car

Las frecuencias por debajo de 433 MHz están prohibidas en Europa, solo se permiten en los países donde están autorizados, cualquier uso o manejo de estas frecuencias es responsabilidad del comprador.

En cumplimiento de la directiva 2014/53/EU

MANUFACTURED BY /FAB: ESB06450563



MANUAL

LIGHTER CAR



CARACTERÍSTICAS TÉCNICAS

- ✓ Modelo LIGHTER CAR
- ✓ Frecuencias 300-900 Mhz
- ✓ 3 Canales
- ✓ CHIP ESPECIAL
- ✓ SOFTWARE NEW CLONER PATENTADO

ATENCIÓN: ESTE MANDO TRABAJA DE DOS FORMAS DIFERENTES:

1. ENTRA DIRECTAMENTE EN EL RECEPTOR
2. CLONA

Instrucciones de programación. **OJO: ES NECESARIO DOS PERSONAS para la entrada directa en el receptor.**

1. Localice los DIP switches en la parte trasera del mando.



Lighter Car

2. Seleccione la combinación correspondiente de DIP switches de acuerdo a la marca deseada. Véasela tabla al final del manual.

3. El mando está listo para usarse. Por favor, **diríjase al manual de usuario de su receptor. Es necesario dar de alta el mando en su receptor. Hacer del siguiente modo:**

- Destape el motor
- Localice la tarjeta receptora
- Localice el botón de ALTA
- Introduzca el LIGHT CAR en el mechero de su coche
- Pulsar el botón de ALTA en el receptor y a continuación pulse en el mando el botón que desee grabar.

Nota: Para BFT, MUTANCODE y ERREKA, será necesaria la utilización del Botón semilla (debajo del led, en la parte delantera del mando).

FAAC también tiene una programación especial, abriendo dicha programación primero en el mando original.

Véase el vídeo en Youtube en el siguiente link: <https://youtu.be/Mx-zUwFlevw>



jj

LIGHTER CAR

Lighter Car

Frequency below 433 MHZ is forbidden in Europe, They are just allowed in countries where they are authorized, any handling and used of these is buyer responsibility.

In compliance with DIRECTIVE 2014/53/EU

MANUFACTURED BY /FAB: ESB06450563



MANUAL LIGHTER CAR



TECHNICAL FEATURES

- ✓ Model LIGHTER CAR
- ✓ Frequencies 300-900 Mhz
- ✓ 3 Channels
- ✓ SPECIAL CHIP
- ✓ SOFTWARE NEW CLONER PATENTED

ATTENTION: THIS REMOTE WORKS IN TWO DIFFERENT WAYS:

1. **ENTERING DIRECTLY IN THE RECEIVER**
2. **CLONING**

Programming instructions: **PAY ATTENTION! IS NECESSARY TWO PEOPLE FOR WORKING TO ENTER DIRECTLY IN THE RECEIVER.**

1. Locate the selector switch in the back of the remote.



2. Select the corresponding combination of DIP switches according to the desired brand. **See the table below.**

Lighter Car

3. The remote is ready to use. Please refer to the user manual of your receiver. **It is necessary to register the command on your receiver. Do as follows:**

- Uncover the motor.
- Locate the receiving card.
- Locate the PROGRAM button.
- Insert the LIGHT CAR into your car's cigarette lighter
- Press the PROGRAMMING button and then press the button you wish to record on the remote control.

Note: For BFT, MUTANCODE and ERREKA, it will be necessary to use the Seed Button (under the led, on the front of the control).

FAAC works in a special way as well. See the Youtube video in the following link:






<https://youtu.be/Mx-zUwFLevw>









Selección de DIPs para entrar directamente en el receptor .
Selection DIP switches to enter directly in the receiver.

Num	DIP SWITCHES	R/F	Brand Marca	Original	Comments Comentarios
1		Rolling Code	APRIMATIC TR 433.92 Mhz		
2		Rolling Code	BENINCA TO GO WV / WP T WV / WK CUPIDO 433.92 Mhz		






Lighter Car

3		Rolling Code	BFT MITTO 433.92 Mhz		Hidden button Botón semilla
4		Rolling Code	CARDIN S449-QZ2 433.92 Mhz		
5		Rolling Code	CENTURION 433.92 Mhz		
6		Rolling Code	DEA (KING SISTEM) GENIE GENIE GREEN/WOOD MIO TR-2 433.92 Mhz		
7		Fixed Code	DITEC GOL4 GOL4C BIXLP2 433.92 Mhz		





Lighter Car

8		Rolling Code	DOORHAN 433.92 Mhz		
9		Rolling Code	ERREKA SOL R SOL4R 433.92 Mhz		Hidden button Botón semilla
10		Rolling Code	FAAC XT 433 RC 433.92 Mhz		Red LED LED rojo
11		Rolling Code	Genie 315 Mhz		
12		Rolling Code	GENIE 390 Mhz		
13		Rolling Code	GIBIDI DOMINO AU1600 433.92 Mhz		







Lighter Car

14		Fixed Code	KEY TXB-42 433.92 Mhz		
15		Fixed Code	KINGATE STYLO4 MYO4 C 433.92 Mhz		
16		Encrypted Code	LIFTMASTER BILLIONCODE 315 Mhz		
17		Encrypted Code	Liftmaster Chamberlain Lobas 390 Mhz		
18		Encrypted Code	Liftmaster Chamberlain Lobas 433.92 Mhz		






Lighter Car

19		Encrypted Code	Liftmaster Chamberlain Lobas 315 Mhz		
20		OPEN CODE	Liftmaster Chamberlain Lobas 390 Mhz		
21		OPEN CODE	Liftmaster Chamberlain Lobas 433.92 Mhz		
22		Encrypted Code	Liftmaster Chamberlain Motorlift 700 Lobas Raynor Orion 315 Mhz		
23		Encrypted Code	Liftmaster Chamberlain Motorlift 700 Lobas Raynor Orion 390 Mhz		





Lighter Car

24		Encrypted Code	Liftmaster Chamberlain Motorlift 700 Lobas Raynor Orion 433.92 Mhz		
25		Fixed Code	Marantec Twobi Raynor New England 433.92 Mhz		
26		Rolling Code	MCT-3 Linear 433 Mhz		
27		Rolling Code	MUTAN CODE 433.92 Mhz		Hidden button Botón semilla
28		Encrypted Code	NICE FLOR-S 433.92 Mhz		
29		Rolling Code	NICESMILO 433.92 Mhz		

Lighter Car

30		Rolling Code	NOVOTROM NOVOFORM TORMATIC 433.92 Mhz		
31		Fixed Code	PRASTEL MPSTF E MPSTP E TRQ P TC E 433.92 Mhz		
32		Fixed Code	PROTECO PTX433405 TX3 433.92 Mhz		
33		Rolling Code	PUJOL VARIO 1 OCEAN 433.92 Mhz		Hidden button Botón semilla
34		Fixed Code	ROGER TX 12 TX14/22 433.92 Mhz		


Lighter Car

35		Rolling Code	SOMMER 433.92 Mhz		
36		Rolling Code	SOMMER 868 Mhz		
37		Fixed Code	TELCOMA TANGO 433.92 Mhz		
38			V2 433.92 Mhz		

CLONE MODE

Programming Instructions

1. Select DIP position chosen brand. Example: FAAC 433, two DIPS up four DIPS down.



2. Press hidden button located in the front of remote control to active the cloning mode.
3. Press the button ONCE AND RELEASE, on the transmitter CLON

Lighter Car

4. Close together the transmitter with the original transmitter
5. Press and hold the button on the original transmitter. Note. If the procedure was copied correctly. The led on the CLON transmitter will 3 flashes.




To use another button, repeat steps 1 to 5.

MODULO CLON

Instrucciones de programación.

1. Seleccionar la posición DIP de la marca deseada.
- Por ej.: FAAC 433, dos DIPS arriba cuatro DIPS abajo.







2. Pulse el botón oculto localizado detrás del mando para activa el modo clon.
3. Pulse UNA SOLA VEZ Y SUELTE uno de los botones del mando CLON
4. Acerque el mando al mando original.
5. Pulse y mantenga el botón del mando original. Nota: Si sigue el procedimiento lo ha hecho correctamente. El led del mando CLON emitirá tres flases.








Para usar cualquier otro botón, repita los pasos 1 a 5






Lighter Car

ITEM	DIP POSITION		BRAND	ORIGINAL	NOTE
1			CLEMSA Mastercode 433.92 Mhz		
2			DITEC 433.92 Mhz		TXD
3			FAAC SLH (Blue led) 433.92 MHZ		TXFA433 NOTA: Es necesario alejarse 15 cm del original para clonar. ATTENTION: It is necessary to distance 15 cm from the original to clone.
4			FAAC SL 868 Mhz	 	
5			Hormann Marantec FAAC Berner BHS	 	

Lighter Car

	1 2 3 4 5 6 		868 Mhz		
6	1 2 3 4 5 6 		Marantec 433.92 Mhz		
7	1 2 3 4 5 6 		Universal fixed code 433.92 Mhz		
8	1 2 3 4 5 6 		Universal rolling code 433.92 Mhz		
9	1 2 3 4 5 6 		V2 433 Mhz		

Lighter Car

10			V2 868 MHz		
11			Fixed code Código fijo 306 Mhz		This frequency is forbbiden for Sales in EUROPE Esta rfrecuencia esta prohibida su venta en Europa
12			Fixed code Código fijo 310 Mhz		This frequency is forbbiden for Sales in EUROPE Esta frecuencia esta prohibida su venta en Europa
13			Fixed code Código fijo 315 Mhz		This frequency is forbbiden for sales in EUROPE Esta frecuencia esta prohibida su venta en Europa
14			Fixed code Código fijo 330 Mhz		This frequency is forbbiden For sales in EUROPE Esta frecuencia esta prohibida su venta en Europa
15			Fixed code Código fijo 390 Mhz		This frequency is forbbiden for sales in EUROPE Esta frecuencia esta prohibida su venta en Europa

Lighter Car

	1 2 3 4 5 6 ↓ ↑ ↑ ↑ ↑ ↑ ↓ ↑				
--	--	--	--	--	--

NOTA: En el LIGHTER CAR se puede poner una marca y frecuencia diferente en cada botón (canal) SÓLO en el MODO CLON.

ATTENTION: In LIGHTER CAR you can put a different brand and frequency in each button (channel) ONLY in CLONE MODE.

LIGHTER CAR